

SPIN HANDLE INSTRUCTIONS

Step 1

- Slip small sleeve over the bolt. (**Figure 1.1**)



Figure 1.1

Step 2

- Slip large sleeve over small sleeve on bolt. (**Figure 2.1**)



Figure 2.1

Step 3

- Insert thru pre-drilled hole. Attach nut and tighten. (**Figure 3.1**)



Figure 3.1